


FTC5 Main Controller



Button	Function
Menu	Access to system settings for initial set up and modifications
Back	Return to previous menu
Confirm	Used to select or save (Enter key)
Power / Holiday Mode	If system is switched off pressing once will turn system on. Pressing again when system is switched on will enable Holiday mode. Holding the button down for 3 secs will turn the system off
Function keys	Used to scroll through menu and adjust settings. Function is determined by visible menu screen

Main Screen Icons	Description
A Legionella Prevention	When this icon is displayed Legionella prevention mode is active
B Heat Pump	'Heat Pump' is running Defrosting Emergency heating
C Electric Heater	When this icon is displayed the 'Electric Heaters' (booster or immersion heater) are in use
D Target Temperature	Target flow temperature (Fixed flow temperature) Target room temperature (Room compensation) Compensation curve (Weather compensation)
E Option Screen	Pressing the function button below this icon displays the option screen, including energy monitoring
F +	Increase desired temperature
G -	Decrease desired temperature
H Z1-Z2 Information	Pressing the function button below this icon switches between Zone 1 and Zone 2 Pressing the function button below this icon displays the information screen
I Space Heating Mode	Heating mode Zone 1 or Zone 2
J DHW Mode	Normal or Eco mode domestic hot water
K Holiday Mode	When this icon is displayed 'Holiday mode' is activated
L	Timer Prohibited Stand-by Stop Operating
M Current Temperature	Current room temperature Current water temperature of DHW tank
N	The Menu button is locked
O	SD memory card is inserted. Normal operation SD memory card inserted. Abnormal operation
P Boiler	When this icon is displayed, the boiler is in use